

## References for the right using of west*aquaristik* aquarium cabinets

- Put the cabinet on a straight underground and a line it if necessary
- Do not put any foam on the cabinet, because this can bend within not supported ranges. Please consider the attached drawings.
- The cleaning of the cabinet has to be done with a dry cloth or a special furniture polish.
- Any contact of the cabinet with water can lead to water damages. Please wipe overflowing water immediately.
- For cabinets with timber trim you should seal the joint between aquarium and cabinet with silicon.
- Take care that the inside of the cabinet is absolutely dry ( if necessary you have to add an aquarium ventilator)

## References for the right using of westaquaristik aquarium covers

westaguaristik

- When setting up the combination, please hold enough distance to the wall or other articles in order to ensure a good ventilation.
- Please consider by opening the cover that you first withdraw the plates so that the condensation water can run off back into the aquarium and then let slide the plates into the appropriate device. So you prevent that water runs out of e.g. the cable or ventilations.
- We recommend to glue the plastic framework on the aquarium with silicon. Thereby the framework is fixed and receives more stability. Also you prevent a dropping of condensation water between aquarium and framework.
- The screws at the lamps are only for the transport and have to be removed later.
- We recommend to turn the stabilization tie bars each week, in order to prevent possible bending.

## Service and Setup Information

westaguaristik

westaquaristik, Inh. M.Weigel, Industriestr.45, 52224 Stolberg Tel: 0049-2402-81141 Fax: 0049-2402-81154 Email:info@westaquaristik.de www.westaquaristik.de